

True Manager Manual

User Manual ver.2

Table of Content

| | |
|--|----|
| 1. True Manager Software..... | 3 |
| 2. Device Registration and Removal..... | 4 |
| 3. Remote Web Server Connection, Setup and Monitoring..... | 8 |
| 4. Setup device..... | 9 |
| 5. Device Connection Management..... | 13 |
| 6. Server Status Monitoring..... | 14 |
| 7. Network and System Diagnostics..... | 16 |
| 8. F/W Upgrade..... | 18 |
| 9. Other Functions..... | 19 |


1. True Manager Software

True Manager is a program used for basic configuration, diagnostics and F/W upgrade of server.

True Manager provides the following features.

- Finding servers on the LAN and assigning IP address
- Monitoring server status: encoding/decoding, serial, sensor and etc.
- Diagnostic function: PING, network bandwidth measurement, video/audio output, port check, serial port check and etc.
- F/W upgrade
- Setup of server and monitoring
- Web setup of server

2. Device Registration and Removal



1) Device Registration

In order to manage servers using True manager, the first step is to register the server. The following steps describe the two ways to register a server.

Add device

- ① Select **Add device** on **Server** menu.
- ② Enter information for connecting to the server at **Add device** dialog.
If the server is registered on DDNS server, domain name can be used instead of IP address. When the IP address of the server is forgotten, it is possible to find the IP address of the server with IP Discovery function. (Please refer to IP Discovery section).
- ③ Press **Add** button.

A screenshot of the 'Add device' dialog box. It contains several input fields: 'Name' with the value 'Device', 'IP/Domain' with the value '192.168.10.100', 'Http port' with the value '80', 'HTTPS Port' with the value '443', 'ID' with the value 'admin', and 'Password' with four dots. At the bottom, there are two buttons: 'Add' and 'Close'.

● Add Multiple devices

| Name | IP address | Base port | Http port | Https port | ID |
|------------------------------|----------------|-----------|-----------|------------|-------|
| <input type="checkbox"/> 100 | 192.168.10.100 | 2222 | 80 | 443 | admin |
| <input type="checkbox"/> 101 | 192.168.10.101 | 2222 | 80 | 443 | admin |
| <input type="checkbox"/> 102 | 192.168.10.102 | 2222 | 80 | 443 | admin |
| <input type="checkbox"/> 103 | 192.168.10.103 | 2222 | 80 | 443 | admin |
| <input type="checkbox"/> 104 | 192.168.10.104 | 2222 | 80 | 443 | admin |
| <input type="checkbox"/> 105 | 192.168.10.105 | 2222 | 80 | 443 | admin |
| <input type="checkbox"/> 106 | 192.168.10.106 | 2222 | 80 | 443 | admin |
| <input type="checkbox"/> 107 | 192.168.10.107 | 2222 | 80 | 443 | admin |
| <input type="checkbox"/> 108 | 192.168.10.108 | 2222 | 80 | 443 | admin |
| <input type="checkbox"/> 109 | 192.168.10.109 | 2222 | 80 | 443 | admin |
| <input type="checkbox"/> 110 | 192.168.10.110 | 2222 | 80 | 443 | admin |
| <input type="checkbox"/> 111 | 192.168.10.111 | 2222 | 80 | 443 | admin |
| <input type="checkbox"/> 112 | 192.168.10.112 | 2222 | 80 | 443 | admin |
| <input type="checkbox"/> 113 | 192.168.10.113 | 2222 | 80 | 443 | admin |
| <input type="checkbox"/> 114 | 192.168.10.114 | 2222 | 80 | 443 | admin |
| <input type="checkbox"/> 115 | 192.168.10.115 | 2222 | 80 | 443 | admin |
| <input type="checkbox"/> 116 | 192.168.10.116 | 2222 | 80 | 443 | admin |
| <input type="checkbox"/> 117 | 192.168.10.117 | 2222 | 80 | 443 | admin |
| <input type="checkbox"/> 118 | 192.168.10.118 | 2222 | 80 | 443 | admin |
| <input type="checkbox"/> 119 | 192.168.10.119 | 2222 | 80 | 443 | admin |
| <input type="checkbox"/> 120 | 192.168.10.120 | 2222 | 80 | 443 | admin |
| <input type="checkbox"/> 121 | 192.168.10.121 | 2222 | 80 | 443 | admin |


61 Setting(s) Generated

This menu is used when specific IP range is registered and IP discovery is not discovered

- ① Select **Add Multiple devices** on **Server** menu.
- ② **Set up IP range:** Click one of 4 check boxes and rest 3 check boxes will be disabled.
The range which is selected in “From and To” are IP addresses to be registered.
- ③ **Server port and Authentication:** Enter information for connecting to the servers.
Same values are adjusted for all registered servers.
- ④ **Name:** They are named by 1 Prefix and 2 selections gradually.
- ⑤ Click **Generate** and then the server information in the registered range will be listed on the left.
- ⑥ Select the check box of the list which are actually needed or click **Select all servers** on the top of Add server table.
- ⑦ **Group:** Select the group on the list or enter new group name.
- ⑧ Click **Add** button.


● IP Discovery

Using **IP Discovery** function, all servers on the same LAN where the PC executing True Manager is located can be found. Furthermore, it is possible to change IP address of a server easily. **IP Discovery** dialog is invoked by pressing **IP Discovery** in Server menu , and it shows all servers on the same LAN.



If you press **Add device** button after selecting a server, the information for the server is automatically entered on **Add Server** dialog. Pressing **IP Change** button after selecting a server invokes a dialog on which IP address of the server can be changed.

It is possible to change IP address of a server which has IP address of different subnet.




2) Removal of a device

A server can be removed by the following steps.

● Remove device

- ① Disconnect a device and right click then select Remove device
- ② Select a device and click remove on the bottom
- ③ Or select Remove device on Server menu



● Remove All Server


- ① Disconnect a device and right click then select Remove device
- ② Check Select all and click remove on the bottom
- ③ Or select Remove all devices on Server menu

3) Modify Device Information

Information for a server can be modified after devices are added.

- ① Disconnect a device and right click then select Modify Device Information on Server menu
- ② Select a device and right click, then select Modify Device Information

3. Remote Web Server Connection, Setup and Monitoring



Server provides web setup page of device, Web viewer of device, Popup viewer of device.

1) Web setup page of device


It opens web setup page on Web browser.

2) Web Viewer

It opens web live view page on Web browser.

3) Popup Viewer


The popup viewer of the selected device will be displayed.



4. Setup device

Setup device allows you to configure System, Video, Audio and Network on True Manager easy and quick.

- ① Select **Setup device** on **Server menu**.
- ② Check the check box of the server to need setup.



System

- System Mode

Select system of the server and click the apply button

- Language

Select the language to be used for web-based configuration

- Time

① NTP server

Select Enable and it automatically synchronized time with an NTP server.

② Current Time

Current date & time

Enter a new date and time and press **Set Current Time** button to update date & time

③ Time Zone

Select time zone of where the camera is installed.

Depending on the time zone, Daylight Saving Time will work automatically

- Factory Reset

All settings including user accounts and logs are cleared.

- **Video**

- **Enable Preview**

- ① Select **ON** to enable to display video on the monitor that is **connected to the composite or HD-SDI video port**.
- ② Select **Preview format** accordingly.

Note that when **Enable Preview is ON**, dual streaming is not available.

When the video is transmitted directly to the monitor through BNC cable, the video does not go through network and encoding. Therefore, there is less delay and no an effect from network limitation.

- **Primary**

- ① **Current input**

It shows current input format

- ② **Input Format**

Select Input Format

- ③ **Resolution**

Select video encoding resolution.

④ Frame rate

Determine the maximum number of frames per second for the video stream.

0.2, 0.4, 0.6, 1, 2, 3, 4, 5, 6, 8, 10, 15, 20, 25, 30 and 60 frame rate can be selected. The actual frame rate of video can be less than the maximum frame rate set due to the network bandwidth limitation

⑤ Preference

Select encoding mode to control video quality or bitrate mode.

⑥ Quality

Select Video quality. 7 levels of quality are available.

⑦ Bitrate

Determine bitrate value between 32 ~ 10240kbps.

⑧ I-Frame Interval

Determine I-frame Interval between 0 and 255.

There will be no I-frames if 0 is selected.

● Audio


- Select the audio algorithm: G.711 or AAC

When AAC is selected, only camera to client delivery is supported. That is, web viewer can't send AAC to the camera.

- Select audio operation mode

| Mode | Action |
|---------|----------------------|
| Off | No operation |
| Tx-Only | Transmit only |
| Rx-Only | Receive only |
| Tx & Rx | Transmit and Receive |

- **Network**



System Video Audio Network

Base port
 2222 * System will reboot after changing base port

Http port
 80

Https port
 443

RTSP port
 554

WS discovery
 On Off

IP fileter
 IP filter setup * Please set carefully.
If you set an invalid value, you cannot access to server.

- **Base Port (1025 ~ 65535)**

Enter the Base Port number.

Network base port is use for communication with remote clients. In order for camera and remote systems (decoder or VMS, NVR software) to be connected, the port number must be identically configured in camera side and client side.

- **HTTP Port (80, 1025 ~ 65535)**

Enter HTTP port used for web-based connection


- **RTSP Port (554, 1025 ~ 65535)**

Enter RTSP port used for RTSP-based connection. The default RTSP port is 554

RTSP (Real Time Streaming Protocol) is a standard for media streaming between server and client.

- **Note :**

Before changing settings, check the box and after setting each sessions, click Apply Settings button under the sessions certainly and they settings are applied.




Apply settings Close

5. Device Connection Management

1) Device Connection

If the check box on the first column in **Servers** (or **Channels/Peripheral**) tab, True Manager tries to connect to the server. If the server is running and the network to the server is normal, it will be connected immediately and **State** will be changed to **Connected**.



| State | Name | IP/Domain Name |
|---|------|----------------|
| <input checked="" type="checkbox"/> Connected | 75 | 192.168.26.75 |
| <input type="checkbox"/> Disconnected | 19 | 192.168.10.19 |

Check box to connect or disconnect server

If it fails to connect to the server due to server or network failure, State displays **Trying connection**. As soon as the server or network is recovered, it will be connected automatically. That is, True Manager periodically retries connection to servers with check box checked.

2) Device disconnection

If the check box is unchecked, the connection to the server is released and **State** displays **Disconnected**.

6. Server Status Monitoring

1) Servers tab – General information

Servers tab shows general information for a connected server: IP/Domain name, MAC address, product model, Type, F/W version, startup time and Power Type. This information comes only for connected servers.

| Servers | | | | | | | | | |
|-------------------------------------|-----------|----------------|-----------------|-------------|------------|----------|----------------|---------------------|-----|
| State | Name | IP/Domain name | Mac address | Model | Type | Firmware | Start up time | Power Type | |
| <input checked="" type="checkbox"/> | Connected | TEST1 | 192.168.143.102 | 00:1C:63... | TN-B22034R | Encoder | V5.004B02_T100 | 2020/06/03 17:25:28 | PoE |

2) Channels tab - Monitoring of video/audio channel state

Channels tab displays how of video channel and audio channel of servers are working.

| Servers | | | | | | | | | | | | | | |
|-------------------------------------|-----------|---------|------------|--------|--------|--------|-------------|------------|-------------|------------|------------|-----------|------------|------------|
| State | Name | Channel | Connection | Camera | Motion | Record | V-E P(kbps) | V-E P(fps) | V-E S(kbps) | V-E S(fps) | V-D (kbps) | V-D (fps) | A-E (kbps) | A-D (kbps) |
| <input checked="" type="checkbox"/> | Connected | TEST1 | 1 | 1 | Ok | | 4158 | 30 | 1049 | 30 | 0 | 0 | 57 | 0 |

| Item | Displays |
|-------------|--|
| Channel | Channel no. |
| Connection | Number of clients connected to a server (including True Manager) |
| Camera | Video loss status |
| Motion | Motion status |
| Record | Record status |
| V-E-P(kbps) | Video encoding bitrate / Video RX / Primary |
| V-E-P(fps) | Video encoding framerate/ Video RX / Primary |
| V-E-S(kbps) | Video decoding bitrate/ Video RX / Secondary |
| V-E-S(fps) | Video decoding framerate/ Video RX / Secondary |
| V-D(kbps) | Video Decoding bitrate/ Video TX |
| V-D(fps) | Video Decoding framerate/ Video TX |
| A-E(kbps) | Audio RX |
| A-E(kbps) | Audio TX |

Depending on the system mode, items which are not relevant to the mode may display 0 always. For example, V-D(kbps) and V-D(fps) are always 0, if the system mode is Encoder.

3) Peripherals tab – Monitoring of serial, sensor and relay port

Peripherals tab displays the status of serial, sensor and relay port.

| Servers Channels Peripherals Settings | | | | | | | | | | | |
|---------------------------------------|-----------|---------|---------|---------|---------|----------|----------|--------|---------|---------|---------|
| State | Name | COM1-TX | COM1-RX | COM2-TX | COM2-RX | Sensor 1 | Sensor 2 | Buzzer | Relay 1 | Relay 2 | SD card |
| <input checked="" type="checkbox"/> | Connected | TEST1 | 0 | 0 | 0 | 0 | Off | Off | Off | Off | Unknown |

| Item | Displays |
|--------------------|---|
| COM1-TX COM1-RX | Activity of RS-232C port - TX: server -> external equipment - RX: external equipment -> server |
| COM2-TX COM2-RX | Activity of RS-422/485 port - TX: server -> external equipment - RX: external equipment -> server |
| Sensor1 Sensor2 | States of sensor ports |
| Buzzer | State of buzzer |
| Relay1 Relay2 | States of relay ports |


4) Settings tab – Monitoring of setting of servers

Settings tab displays the status of setting of servers

| Servers Channels Peripherals Settings | | | | | | | | | | | | |
|---------------------------------------|--------------|---------------|--------------|---------------|--------------|--------------|----------------|-----------------|------------|------------|-------------|----|
| State | Name | Mode | Preview | Output format | Input format | Resolution | Framerate | Preference | Quality | Bitrate | IF interval | |
| <input checked="" type="checkbox"/> | Connected | TEST1 | Encoder | Off | 480i60 | HDMI 1080p60 | 1920x1080 | 30 | CBR | - | 4000 | 30 |
| Use secondary | Algorithm(s) | Resolution(s) | Framerate(s) | Preference(s) | Quality(s) | Bitrate(s) | IF interval(s) | Audio algorithm | Audio mode | Audio gain | | |
| On | H.264 | 720x480 | 30 | CBR | - | 1024 | 30 | G.711 | Tx & Rx | 25 | | |

7. Network and System Diagnostics

- True Manager provides various diagnostic features with which the reason for the following situations can be found.
- Connection between two servers, or between a server and VMS(Video Management System) is not established.
- Video, audio or serial data are not delivered as configured.
- Video and/or audio outputs don't come on output port.



1) Dos Ping

Dos table is displayed with by selecting **Ping Test** on **Tools** menu after selecting a server.

It checks internet connection status of a server.

```

C:\Windows\System32\ping.exe
Reply from 192.168.26.75: bytes=32 time=1ms TTL=64
Reply from 192.168.26.75: bytes=32 time=2ms TTL=64
Reply from 192.168.26.75: bytes=32 time=5ms TTL=64
Reply from 192.168.26.75: bytes=32 time=8ms TTL=64
Reply from 192.168.26.75: bytes=32 time=8ms TTL=64
Reply from 192.168.26.75: bytes=32 time=5ms TTL=64
Reply from 192.168.26.75: bytes=32 time=4ms TTL=64
Reply from 192.168.26.75: bytes=32 time=8ms TTL=64
Reply from 192.168.26.75: bytes=32 time=8ms TTL=64

```

2) Execute "arp -d"


ARP (Address Resolution Protocol)

Execute "arp-d" command delete ARP information and reset ARP data and reset ARP data.

3) Log

The log in a server can be viewed by selecting **Log** on **Tools** menu.

System log, User, System status, dmesg, netstat, bmstat, df and ps logs are available.



4) Reboot

A device or all devices can be rebooted by selecting **Reboot** on **Tools** menu.

5) Factory Reset

All settings including user accounts and logs will be cleared.

A device or all devices can be factory reset by selecting **Factory Reset** on **Tools** menu.


6) Options

Designate the OS explorer program to use for web connection.

In case of using 64bit OS program, the explorer should be changed to the 32bit.

8. F/W Upgrade

When **Update** is selected on **Tools** menu, the dialog for F/W upgrade comes.




- ① Select a server to upgrade (check the check box in **Sel** column). More than one server can be upgraded simultaneously.
- ② Select an upgrade file.
- ③ Press **Upgrade** button.
- ④ Wait until **Progress** is changed to **Upgrade succeeded**.

When network condition is poor, upgrade may fail. In such case, please retry above procedure after network condition is recovered.

Caution: Don't power-off the server while upgrade is in progress. The server may go to irrecoverable state.


9. Other Functions

1) Grouping of servers




When there is large number of servers, it is convenient to manage servers in several groups. Using **Add Group** and **Remove Group** on **Group** menu, server group can be created and deleted. **Modify Group** menu is used to add servers to a group or to remove servers from a group.

And the Group is appeared on the left of true manager page.




2) Checking Disk

Verify the status of the selected server.



3) File Setup



- **New**

New true manager file is created.

- **Save as**

A true manager file is saved and the file is appeared on the left of true manager page.

- **Open**

Open the saved files.

- **Exit**

Exit from the using true manager.