

Figure 2 : ANT-375000D with Dante AV-H[™] screen at start up



The IP address, and other information, for the ANT-37500D is displayed at the bottom of the screen for $10 \sim 15$ seconds. This information is shown in Figure 3. This information can be shown at time by pressing the "menu" button the remote control.

Figure 3 : ANT-37500 information shown in HDMI monitor



This information is

- A. The current time within the ANT-37500D 15:08:30
- B. The version of firmware installed 3.5.12
- C. The MAC address of the ANT-37500D 8c:1f:64:a1:bf:ff
- D. The IP address currently be used by the ANT-37500D 192.168.0.201

2. Using Dante Controller

In this example version the Dante Controller used is shown in Figure 4

Figure 4 : Dante Controller version



When Dante Controller is started it will discovery and display all Dante enabled devices. An example is shown in Figure 5. The "Device Info" tab, see Figure 6, will show the model, versions and IP address.

NOTE: the last 6 digits and the devices "name" show in the "Routing" view are the last 6 digits of the MAC address. This could be used to determine the ANT-37500D by the MAC address information that is displayed on the monitor at power up.



🥩 Dante Controller - Network View					<u> </u>		×
File Devices View Help							
	6	Pri 🕥	mary Leader Clock: ANT-AV-H-a1bfff				0
Routing Device Info Clock Status Network Sta	itus E	ents					
Filter Transmitters	UV430E-a9c03d						
H ANT-AV-H-808802	ŦŦ						
+ ANT-AV-H-a1b076	ŦŦ						
+ ANT-AV-H-a1bfff	H H						
+ UV430E-a9c03d	H H						
± UV430E-a9cad0	ΞŦ						
P: 🔲 S: 🛄		5 devices	Multicast Audio Bandwidth: Obp	s EventLog: 📃	Clock Sta	tus Monito	or: 📃

Figure 6 : Dante Controller - "Device Info"

a Devices View	Lista							
lie Devices view	пеір		2					
🗋 😏 💼 🖌					Primary Leader Cloc	k: ANT-AV-H-a1bfff		
louting Device Info	Clock Status Network	Status Events						
Device Name	Model Name	Product Version	Dante Version	Device Lock	Primary Address	Primary Link Speed	Secondary Address	Secondary Link Speed
ANT-AV-H-808802	ANT37500 AV-H	3.5.12	1.1.0.1		192.168.0.208	100Mbps	N/A	N/A
ANT-AV-H-a1b076	ANT37500 AV-H	3.5.12	1.1.0.1		192.168.0.7	100Mbps	N/A	N/A
ANT-AV-H-a1bfff	ANT37500 AV-H	3.5.12	1.1.0.1		192.168.0.6	1Gbps	N/A	N/A
UV430E-a9c03d	UV430E	3.0.1	1.1.0.1		192.168.0.196	1Gbps	N/A	N/A
	UV430E	3.0.1	1.1.0.1		192.168.0.195	1Gbps	N/A	N/A

To configure the ANT-37500Dthere needs to be "transmitters" device(s) on the network and the ANT-37500 is a "Receivers" device.

In the Routing view click the "+" symbol to expand all the devices, as shown in Figure 7.



Figure 7 : Dante Controller - Routing view with devices expanded



In the example in Figure 8, the video and 2 audio channels from UV430E-a9cad0 (which is a camera) will be sent to the ANT-37500D ANT-AV-H-a1bfff. To do this the click the boxes where the relevant signals cross, as shown by the green ticks. An overview is shown in Table 1.

7	able	1	:	Camera	to	decoder	connection
•		_	-				

	Source	receiver
A/V	UV430E-a9cad0	ANT-AV-H-a1bfff
Video	01	01
Audio	01	01
Audio	02	02

Figure 8 : Dante Controller ANT-37500 displaying video and audio

👳 Dante Controller - Network View					
File Devices View Help					
	٥	0		Q	Primary
Routing Device Info Clock Status Network S	Statu	is Ev	ents		
A Dante Filter Transmitters		V430E-a9c03d - 01 ⊡ -	58	/430E-a9cad0 -	00 0
Filter Receivers	I I ransmitters (2	5		5	
	ŧ	=		-	
- 0 01 - 0 02					
ANT-AV-H-a1b076		Ξ			
ANT-AV-H-a1bfff		Ξ		7	000
UV430E-a9c03d 0 01 0 02		Ξ		E	~
UV430E-a9cad0					
P: 🔲 S: 🛄 5 de	evice	25			



ANT-37500D Quick start guide

Contents

ANT-375 Docume	500D Quick start guide	.1 .1
1.	Setup out of Box	.1
2.	Using Dante Controller	. 2

Please note some of the images used in this guide show the ANT-37500D firmware as 3.5.12. The latest version (as of 7-May-24) is 3.5.14.

Any later versions can be found in the website folder https://downloads.antrica.com/Decoders/ANT-37500D/Firmware/Current-Firmware/

1. Setup out of Box

The ANT-37500D decoder currently has firmware 3.5.14 or higher installed. The latest version an be found in the folder https://downloads.antrica.com/Decoders/ANT-37500D/Firmware/Current-Firmware/

The default network setting is DHCP.

If there is no DHCP server on the network to assign an IP address then ANT-37500D will selfassign an IP address starting 169.xxx.xxx. The "Dante Controller" application will only discover the ANT-37500D only if the ANT-37500D is one the same network as the "Dante Controller" PC. If The ANT-37500D is using its own self assigned IP address then it may not be discovered "Dante Controller".

Referring to Figure 1, connect:

- 1. the Ethernet to a network switch
- 2. the HDMI to a monitor
- 3. Finally connect power
- 4. Once fully booted the Dante AV-H[™] screen will be seen, as shown in Figure 2.

I AN HDMI2.0 power input (USB C) HDMI output to monitor Ethernet

Figure 1 : ANT-37500 "back" of unit

For further help and advice please contact Antrica on: Email: support@antrica.com Phone: +44 1628 626098, during UK office hours, and ask for technical support

Document info

Version	date	author	Comments
0.1	24-Apr-24	David M	Initial draft – using 3.5.12
0.2	7-May-24	David M	Initial release – firmware is 3.5.14 but images have not been updated
0.3	10-May-24	David	Layout changes - firmware is 3.5.14 but images have not been updated