Contents

ANT-201x

For products based on the ANT-2010,
e.g. ANT-2010, ANT-2014

1. LED

1.1.   Green – Ethernet link is good

When a Ethernet link is connected this LED is permanently on

1.2.   Yellow – unit is booting

On for a brief period during bootup, either power up or reset, normally this LED
will be off

1.3.   Red - Power is present

This LED is on all the time to indicate power is present

2. LAN

2.1.   Green – Link speed

Off is no link
Slow flashing is 1000 Mbps
Solid on is 100 Mbps

2.2.   Yellow – network activity

Flashing to indicate network activity