

See below instructions:

- The Red areas on the Nn Main and HDMI files should be masked
- The flux removal, see attached, should be applied before coating
- The coating material should be a mixture of the materials defined in Versatill ZT and 1B31

Please also inform the customer that we're using Aim Solder M8 solder paste.









