

ANT-37500 - front panel factory reset

Contents

ANT-37500 – front panel factory reset	
Overview	
Document info	
1. "Front" / push button factory reset	
• •	
1.1. Instruction for push button factory reset	۷ ۷

Overview

To reset the ANT-37500 the process uses the front panel button

- 1. Full Factory reset
- 2. Connect ALL connections (HDMI, Ethernet and power)
- 3. Apply power
- 4. Front panel LED will be off wait
- 5. Front panel LED will be on permanently wait
- 6. Front panel LED will flash step 6. NOW
- 7. During the time the blue led is flashing, press and hold down the front button this button is small and recessed so it is not as easy to press and hold it.
- 8. After the LED has turned red release the front button. Release as soon as the LED is red, do not wait.
- 9. The ANT-37500 execute factory reset and reboot.
- 10. The access IP address is now 192.168.0.222

For further help and advice please contact Antrica on:

Email: support@antrica.com

Phone: +44 1628 626098, during UK office hours, and

ask for technical support

Document info

Version	date	author	Comments
0.1	24-Nov-23	David M	Initial draft



"Front" / push button factory reset

The ANT-37500 can be factory reset by using the small button on the front panel, as shown in Figure 1.

Figure 1 : ANT-37500 "front" panel



1.1. Instruction for push button factory reset

- 1. Connect ALL connections (HDMI, Ethernet and power)
- 2. Apply power
- 3. Front panel LED will be off wait
- 4. Front panel LED will be on permanently with a blue colour wait
- 5. Front panel LED will flash blue step 6. NOW
- 6. During the time the blue LED is flashing, press and hold down the front button, this button is small and recessed so not easy to press in.
- 7. After the LED has turned red release the front button. **Release as soon as the LED is red**, do not wait.
- 8. The ANT-37500 will execute factory reset see Figure 2 for image seen on HDMI.
- 9. When the reset is complete, see Figure 3, the ANT-37500 will self-reboot. No intervention is required.
- 10. The access IP address is now 192.168.0.222, see Figure 4




Figure 2: ANT-37500 during factory reset



Figure 3: ANT-37500 when reset is complete



Figure 4: ANT-37500 in factory reset mode



For infomation use only Page 3 of 3 last saved: 24-Nov-23