

ANT-3xxxx end panel and case sizes

Contents

ANT-3xxxx end panel and case sizes	1
Document info.....	1
1. End panels.....	2
2. Case sizes	2

For further help and advice please contact Antrica on:
Email: support@antrica.com
Phone: +44 1628 626098, during UK office hours, and
ask for technical support

Document info

Version	date	author	Comments
0.1	14-Jul-23	David M	Initial draft
0.2	5-Jan-23	David M	Add correct part numbers

1. End panels

Figure 1 : **New 35100A** - LED + Reset




Figure 2 : **ANT-35000A** - LED + reset




Figure 3 : **New ANT-35100A** - Power




Figure 4 : **ANT-35000A** - Power




Figure 5 : **new 35100H** - LED + Reset




Figure 6 : **ANT-35000H** - LED + reset




Figure 7 : **new 35100H** - Power




Figure 8 : **ANT-35000H** - Power




Figure 9 : **ANT-39000** - LED + Reset





Figure 10 : **ANT-39000** - Power



2. Case sizes

Products	width	Length	height	comments
ANT-39000	134	125.2	33.0	
ANT-35000A	134	125	33	
ANT-35000H	134	125	33	
ANT-35100H	134	125	33	Non SDI
ANT-35100A	134	125	33	SDI

Width - is "across" the end panel

Length - is from end panel to end panel, including the end panel thickness, but not including any protrusion for connectors, LED etc