



Serial Port and its applications in ANT-4000E/D


Version 1.1

September 22, 2012



This document is confidential and subject to change

Serial Ports in ANT-4000E/DT/ANT-4000E/DR

Transmitter (ANT_4000E)♪




Receiver (ANT_4000D)♪



- 1. 3.3V
- 2. TX-D from ANT4000(Console Port)
- 3. RX-D to ANT-4000(Console Port)
- 4. GND
- 5. TX-D from 4000
- 6. RX-D to 4000

Use Pursuant to Company Instructions

Virtual Serial Cable function (PTZ Camera)



Virtual Serial Cable function (Touch Display)

