

AI Hailo 8 - How to deploy AI Models to ANT-1776X Range that Has Hailo 8 Chip

How to deploy the AI models on the board.

Download the following folder "ai_models" with files of the AI models:

<https://we.tl/t-xilDVWglvs>

They should be copied to the board. The steps are as follows:
Connect to the board via FTP -> Copy the files I provide into the ai_models folder -> Reboot the board.

Video showing the full procedure is here:

<https://we.tl/t-Nr2S2bcfkt>

If the ai_models folder does not exist, you first need to update the board using the update file

partial-V1.1.6.0.35-D03_12_2024-14_25_50.tar.bz2:

<https://we.tl/t-oZebAZuLYC>

After the update, connect via FTP, delete the existing files in ai_models (if any) and copy the new files there as described above.